

# William Stallings

# Computer Organization and Architecture

---

## Chapter 8

## Computer Arithmetic


# Arithmetic & Logic Unit

---

- ⌘ Does the calculations
- ⌘ Everything else in the computer is there to service this unit
- ⌘ Handles integers
- ⌘ May handle floating point (real) numbers
- ⌘ May be separate FPU (maths co-processor)
- ⌘ May be on chip separate FPU (486DX +)

# ALU Inputs and Outputs

---



# Integer Representation

---

- ⌘ Only have 0 & 1 to represent everything
- ⌘ Positive numbers stored in binary
  - ☒ e.g.  $41 = 00101001$
- ⌘ No minus sign
- ⌘ No period
- ⌘ Sign-Magnitude
- ⌘ Two's compliment

# Sign-Magnitude

---

⌘ Left most bit is sign bit

⌘ 0 means positive

⌘ 1 means negative

⌘  $+18 = 00010010$

⌘  $-18 = 10010010$

⌘ Problems

☒ Need to consider both sign and magnitude in arithmetic

☒ Two representations of zero (+0 and -0)

# Two's Complement

---

$$\text{⌘} + 3 = 00000011$$

$$\text{⌘} + 2 = 00000010$$

$$\text{⌘} + 1 = 00000001$$

$$\text{⌘} + 0 = 00000000$$

$$\text{⌘} - 1 = 11111111$$

$$\text{⌘} - 2 = 11111110$$


$$\text{⌘} - 3 = 11111101$$

# Benefits


---

- ⌘ One representation of zero
- ⌘ Arithmetic works easily (see later)
- ⌘ Negating is fairly easy
  - ☑  $3 = 00000011$
  - ☑ Boolean complement gives  $11111100$
  - ☑ Add 1 to LSB  $11111101$

# Geometric Depiction of Twos Complement Integers



(a) 4-bit numbers



(b) n-bit numbers



# Negation Special Case 1

---

⌘ 0 = 00000000

⌘ Bitwise not 11111111

⌘ Add 1 to LSB +1

⌘ Result 1 00000000

⌘ Overflow is ignored, so:

⌘ - 0 = 0 ✓

# Negation Special Case 2

---

⌘ -128 = 10000000

⌘ bitwise not 01111111

⌘ Add 1 to LSB +1

⌘ Result 10000000

⌘ So:

⌘  $-(-128) = -128$  X

⌘ Monitor MSB (sign bit)

⌘ It should change during negation

# Range of Numbers

---

⌘ 8 bit 2s compliment

$$\boxed{\wedge} +127 = 01111111 = 2^7 - 1$$

$$\boxed{\wedge} -128 = 10000000 = -2^7$$

⌘ 16 bit 2s compliment

$$\boxed{\wedge} +32767 = 01111111 11111111 = 2^{15} - 1$$

$$\boxed{\wedge} -32768 = 10000000 00000000 = -2^{15}$$

# Conversion Between Lengths

---

⌘ Positive number pack with leading zeros

⌘ +18 = 00010010

⌘ +18 = 00000000 00010010

⌘ Negative numbers pack with leading ones

⌘ -18 = 10010010

⌘ -18 = 11111111 10010010

⌘ i.e. pack with MSB (sign bit)


# Addition and Subtraction

---

- ⌘ Normal binary addition
- ⌘ Monitor sign bit for overflow
  
- ⌘ Take twos compliment of subtrahend and add to minuend
  - ⊠ i.e.  $a - b = a + (-b)$
  
- ⌘ So we only need addition and complement circuits

# Hardware for Addition and Subtraction

---



OF = overflow bit  
SW = Switch (select addition or subtraction)

# Multiplication

---

- ⌘ Complex
- ⌘ Work out partial product for each digit
- ⌘ Take care with place value (column)
- ⌘ Add partial products

# Multiplication Example

---

⌘ 1011 Multiplicand (11 dec)

⌘ x 1101 Multiplier (13 dec)

⌘ 1011 Partial products

⌘ 0000 Note: if multiplier bit is 1 copy

⌘ 1011 multiplicand (place value)

⌘ 1011 otherwise zero


⌘ 10001111 Product (143 dec)

⌘ Note: need double length result



# Unsigned Binary Multiplication

---



(a) Block Diagram


# Execution of Example

---

C	A	Q	M		
0	0000	1101	1011	Initial Values	
0	1011	1101	1011	Add	} First Cycle
0	0101	1110	1011	Shift	
0	0010	1111	1011	Shift	} Second Cycle
0	1101	1111	1011	Add	} Third Cycle
0	0110	1111	1011	Shift	
1	0001	1111	1011	Add	} Fourth Cycle
0	1000	1111	1011	Shift	

# Flowchart for Unsigned Binary Multiplication

---



# Multiplying Negative Numbers

---

⌘ This does not work!

⌘ Solution 1

- ☑ Convert to positive if required

- ☑ Multiply as above


- ☑ If signs were different, negate answer

⌘ Solution 2

- ☑ Booth's algorithm

# Booth's Algorithm

---



# Example of Booth's Algorithm

---

A	Q	Q <sub>-1</sub>	M		
0000	0011	0	0111	Initial Values	
1001	0011	0	0111	A	} First Cycle
1100	1001	1	0111	Shift	
1110	0100	1	0111	Shift	} Second Cycle
0101	0100	1	0111	A	
0010	1010	0	0111	Shift	} Third Cycle
0001	0101	0	0111	Shift	
					} Fourth Cycle


# Division

---

- ⌘ More complex than multiplication
- ⌘ Negative numbers are really bad!
- ⌘ Based on long division

# Division of Unsigned Binary Integers

---





# Real Numbers

---

⌘ Numbers with fractions

⌘ Could be done in pure binary

☑  $1001.1010 = 2^4 + 2^0 + 2^{-1} + 2^{-3} = 9.625$

⌘ Where is the binary point?

⌘ Fixed?

☑ Very limited

⌘ Moving?

☑ How do you show where it is?

# Floating Point

---

Sign bit	Biased Exponent	Significand or Mantissa
----------	-----------------	-------------------------

⌘  $+/- \text{ .significand } \times 2^{\text{exponent}}$


⌘ Misnomer

⌘ Point is actually fixed between sign bit and body of mantissa

⌘ Exponent indicates place value (point position)

# Floating Point Examples

---



(a) Format

0.11010001	$2^{10100}$	=	0	10010011	101000100000000000000000
-0.11010001	$2^{10100}$	=	1	10010011	101000100000000000000000
0.11010001	$2^{-10100}$	=	0	01101011	101000100000000000000000
-0.11010001	$2^{-10100}$	=	1	01101011	101000100000000000000000

(b) Examples

# Signs for Floating Point

---

- ⌘ Mantissa is stored in 2s compliment
- ⌘ Exponent is in excess or biased notation
  - ☑ e.g. Excess (bias) 128 means
  - ☑ 8 bit exponent field
  - ☑ Pure value range 0-255
  - ☑ Subtract 128 to get correct value
  - ☑ Range -128 to +127

# Normalization

---

- ⌘ FP numbers are usually normalized
- ⌘ i.e. exponent is adjusted so that leading bit (MSB) of mantissa is 1
- ⌘ Since it is always 1 there is no need to store it
- ⌘ (c.f. Scientific notation where numbers are normalized to give a single digit before the decimal point
- ⌘ e.g.  $3.123 \times 10^3$ )

# FP Ranges

---

⌘ For a 32 bit number

☑ 8 bit exponent

☑ +/-  $2^{256} \approx 1.5 \times 10^{77}$

⌘ Accuracy


☑ The effect of changing lsb of mantissa

☑ 23 bit mantissa  $2^{-23} \approx 1.2 \times 10^{-7}$


☑ About 6 decimal places

# Expressible Numbers

---



(a) Twos Complement Integers



(b) Floating-Point Numbers

# IEEE 754

---

- ⌘ Standard for floating point storage
- ⌘ 32 and 64 bit standards
- ⌘ 8 and 11 bit exponent respectively
- ⌘ Extended formats (both mantissa and exponent) for intermediate results



# FP Arithmetic +/-

---


- ⌘ Check for zeros
- ⌘ Align significands (adjusting exponents)
- ⌘ Add or subtract significands
- ⌘ Normalize result

# FP Arithmetic $\times/\div$

---


- ⌘ Check for zero
- ⌘ Add/subtract exponents
- ⌘ Multiply/divide significands (watch sign)
- ⌘ Normalize
- ⌘ Round
- ⌘ All intermediate results should be in double length storage

# Floating Point Multiplication



# Floating Point Division

---



# Required Reading

---

⌘ Stallings Chapter 8

⌘ IEEE 754 on IEEE Web site